

- 1. Clean the roof area to be covered, and wax the area with a high-quality paste wax.
- 2. Open the moonroof.

5.

Remove the adhesive backing from one protective

tape. Starting at the bottom edge, wrap 6 mm of

protective tape around the lip of the moonroof opening just in front of the mark; continue upward with the tape around the top of the roof panel.

- 6. Repeat steps 3 thru 5 to install the protective tape on the right side of the moonroof opening. Remove the marks you made using isopropyl alcohol on a shop towel.
- 7. Place the two brackets into position over the protective tape and around the lip of the roof opening, and tape them into position with a piece of masking tape.



8. Set the moonroof visor on the vehicle roof in front of the moonroof opening, and adjust its position so the holes in the visor are aligned with the bracket holes. Install two screws and nuts loosely onto the brackets.



9. Position the moonroof visor with equal spacing on all sides. Check that the rubber seal is not twisted or rolled under the visor.



11. Tighten the nuts and screws, alternating between sides. To prevent damage to the moonroof visor and the resin nuts, do not overtighten the screws.

CARE OF THE MOONROOF VISOR

- To avoid damaging the surface, never use ammonia-based cleaners or solvents to clean the moonroof visor.
- Clean with a solution of mild dishwashing soap and water using a soft cloth or chamois.
- To remove fine scratches and restore the original luster, use Meguiar's Mirror Glaze plastic cleaner and polish or an equivalent high-quality plastic cleaner.