


PARTS LIST




INSTALLATION

NOTE:

- Before installing, identify each floor mat.
- Remove the standard floor mats before installing these new floor mats.
- The floor mat anchors are required for the driver's side of the vehicle; the anchors help prevent the driver's side floor mat from sliding forward and interfering with the pedals.

1. Install the driver's side front floor mat by placing the two rings in the floor mat over the two anchors on the floor carpet.



- 2. Install the passenger's side front floor mat by placing the ring in the floor mat over one anchor on the floor carpet.
- 3. Install the rear floor mat by placing the two rings in the floor mat over the two anchors on the floor carpet.

