



# INSTALLATION INSTRUCTIONS

Accessory  
ALL-SEASON FLOOR MATS


Application  
2010 MDX

Publications No.  
BII 42074  
Issue Date  
JAN 2010


Put this information in the glove box with the vehicle owner's manual.

## PARTS LIST


Driver's side all-season floor mat



Passenger's side all-season floor mat



Rear all-season floor mat




## INSTALLATION

### NOTE:

- Before installing the mats, identify their installation positions.
- The anchors prevent the mat from sliding forward and possibly interfering with the pedals.
- If you remove the mat, make sure you reanchor it when you put it back in your vehicle.
- If you replace the mats, use factory mats designed to be used with the anchors.
- If you use a non-factory mat in the driver's footwell, make sure it fits properly and that it can be used with the anchor.
- Do not put an additional mat on top of the anchored mat, otherwise the additional mat may slide forward and possibly interfere with the pedals.
- Identify each mat by the marks on the back of each mat: the mat marked "R" go on the right side of the vehicle; the mat marked "L" go on the left side.

1. Install the driver's side all-season floor mat by placing the two rings in the driver's side all-season floor mat over the two anchors on the floor carpet.



2. Install the passenger's side all-season floor mat by placing the ring in the passenger's side all-season floor mat over one anchor on the floor carpet.
3. Install the rear all-season floor mat by placing the two rings in the rear all-season floor mat over the two anchors on the floor carpet.

