
	Accessory	Application	Publications No.
INSTALLATION			BII 41999
INSTRUCTIONS	ALL SEASON MATS	2010 RL	Issue Date JUNE 2009
ARTS LIST	IN	STALLATION	
river's all season mat	NC	DTE:	
		The anchors prevent the n possibly interfering with th	e pedals.
		If you remove the front ma when you put it back in yo	ur vehicle.
		If you replace the front may to be used with the ancho	
'assenger's all season mat		If you use a non-factory m make sure it fits properly a the anchors.	
		Do not put another mat on the additional mat may slid the pedals.	
eft rear all season mat		Identify each mat by the n marked "R" or "Passenger of the vehicle; the mats ma on the left side.	's side" go on the right sid
			nchor one quarter turn, ar I passenger's vehicle floor
light rear all season mat		ANCHOR TAB (Turn.)	VEHICLE FLOOR MAT
			ANCHOR
		PASSENGER'S SEAT VEHICLE FLOOR MAT	DRIVER'S SEAT VEHICLE

2. Position the driver's and passenger's all season mats by aligning the tabs with their anchors.



- 3. Turn the tabs of each anchor one quarter turn to secure the driver's and passenger's all season mats.
- 4. Position the rear all season mats as shown.

