



23. Adjust the position of the running board as shown. Tighten the four 8 x 16 mm flange bolts and four flange nuts loosely installed in step 18 in the order **1** → **2**. Torque the flange bolts to 22 N·m (2.2 kgf·m, 16 lbf·ft).



24. Visually check that the left running board is installed parallel to the vehicle.



25. Repeat steps 15 through 24 on the right side of the vehicle.